

How to install the library ssd1306

1) You have to connect your Raspberry pi pico to computer.

2) Click Tools and manage packages.

Thonny - C:\Users\Usuario\Documents\raspberry_pi_pico\oled_ssd1306\ssd1306.py @ 30 : 1

Fichero Editar Visualización Ejecutar Herramientas Ayuda


ssd1306.py ×

```
1 from machine import I2C
2 import time
3 from ssd1306 import SSD1306_I2C
4
5 i2c = I2C(0,sda=Pin(0),scl=Pin(1),freq=40000)
6 oled = SSD1306_I2C(128,64,i2c)
7
8 oled.fill(0)
9 aux = 10
10 while True:
11     for i in range(11):
12         number = str(i)
13         oled.text(number,aux,10)
14         oled.show()
15         time.sleep(1)
16         aux = aux + 10
17     aux = 10
18     oled.fill(1)
19     time.sleep(0.2)
20     oled.fill(0)
21     time.sleep(0.2)
22
```


Gestionar paquetes...
Abre el shell del sistema...
Abre la carpeta Thonny program...
Abre la carpeta Thonny data...
Administra plug-ins...
Opciones...

3) Write the next link:


<https://github.com/stlehmann/micropython-ssd1306>




4) Click here.



5) Click on install box.



6) If it was installed successfully you will get this window:



7) Click Close.