

# CC31xx SLS Get Weather Application

## Overview and application details

This sample application demonstrates how to connect to **openweathermap.org** server and request for weather details of a city. The application opens a TCP socket w/ the server and sends a HTTP **Get** request to get the weather details. The received data is processed and displayed on the console

[Return to CC31xx & CC32xx Home Page](#)[Return to CC31xx Sample Applications](#)

For information on how to use Visual-Studio or Eclipse to compile and run this application, refer to `cc3100_getting_started_guide_swru375` <sup>[1]</sup> in '<cc3100/>docs' folder.

By default, this application communicates w/ CC3100 over SPI. The SDK has UART-Drivers as well for 'SimpleLink Studio' platform. For using the UART interface to communicate w/ CC3100, macro **SL\_IF\_TYPE\_UART** has to be defined in the application-project's properties. Also, 'COMM\_PORT\_NUM' in **main.c** needs to be changed to the first com-port that gets enumerated for 'J6' of 'CC31xxEMUBOOST Brd'. In case four ports are getting enumerated, user should use the third com-port.

**Note:** This wiki page is only applicable for **CC3100-SDK v1.0.0** and upward releases. For documentation on older SDKs' examples, refer corresponding file in <cc3100-sdk-installation-location>\cc3100-sdk\docs\examples\

## Source Files briefly explained

i. **main** - Initializes the device, connects to an AP, opens a TCP socket, requests and displays the weather information.

## Usage

**Prerequisite:** Internet connectivity is required to work w/ this application

- Build and launch the application using Visual-Studio or Eclipse.
- The application requests user for the AP's SSID and security parameters for establishing the connection. It also requests user for the city's name for getting the weather information. Enter the required information on the console

The application connects to the weather-server and opens an TCP socket to communicate w/ it. It receives and processes the weather-information and displays it on the console

- On success, below message will be displayed on the terminal

```
*****
CC3100 Get weather App
1.2.0
*****
Device is configured in default state
Device started as STATION
Please input the SSID you wish to connect to:
TP-LINK-152
Encryption Types:
1: Open
2: WEP
3: WPA
Please enter the corresponding number for the encryption type:
1
Connecting to AP TP-LINK-152...
Connection established w/ AP and IP is acquired

Enter the city name or "QUIT" to quit#:
Bangalore

*****
City:
Bangalore
Temperature:
84.25 F
Weather Condition:
Sky is Clear

*****

Enter the city name or "QUIT" to quit#:
```

## Limitations/Known Issues

None

## References

[1] <http://www.ti.com/lit/pdf/swru375>

# Article Sources and Contributors

**CC31xx SLS Get Weather Application** *Source:* <http://processors.wiki.ti.com/index.php?oldid=193667> *Contributors:* A0131814, A0132173, A0221015, Codycooke, Malokyle, Raghshenoy

## Image Sources, Licenses and Contributors

**File:Cc31xx cc32xx return home.png** *Source:* [http://processors.wiki.ti.com/index.php?title=File:Cc31xx\\_cc32xx\\_return\\_home.png](http://processors.wiki.ti.com/index.php?title=File:Cc31xx_cc32xx_return_home.png) *License:* unknown *Contributors:* A0221015

**File:Cc31xx return sample apps.png** *Source:* [http://processors.wiki.ti.com/index.php?title=File:Cc31xx\\_return\\_sample\\_apps.png](http://processors.wiki.ti.com/index.php?title=File:Cc31xx_return_sample_apps.png) *License:* unknown *Contributors:* A0221015

**Image:Scrsot\_sls\_get\_weather.png** *Source:* [http://processors.wiki.ti.com/index.php?title=File:Scrsot\\_sls\\_get\\_weather.png](http://processors.wiki.ti.com/index.php?title=File:Scrsot_sls_get_weather.png) *License:* unknown *Contributors:* Raghshenoy